


# ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0300

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

**NOTES:** 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. READ AND SAVE THIS INSTRUCTION.

## Hardware Package (included):





## Installation Steps

Turn off the power at fuse or circuit box.

1. Rod Connections:
  - a. Thread the fixture wire from the fixture through the lower rod, then secure the lower rod onto fixture using the threaded pipe.
  - b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
  - c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.

**Note: Length adjustable from 13-5/8" to 55-5/8". Use fewer rods if shorter length is desired.**
2. Thread the fixture wire through the canopy kit, then secure the rod assembly to the set threaded pipe of the canopy kit.
3. Thread two fixture mounting screws (B) through the mounting strap (A), and then secure with two lock nuts (E). Adjust the length of the fixture mounting screws (B) if necessary .
4. Attach the mounting strap (A) to outlet box by using two mounting screws (B).
5. Pull out the source wires from the outlet box. Make wire connections using wire connectors (C) as follows:
  - Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
  - Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
  - Attach the fixture ground wire to the mounting strap (C) with the green ground screw. Then connect it to the house ground wire with wire connector (C).
6. Attach the canopy kit to the mounting strap (A) by inserting the fixture mounting screws (D), then secure it with two ball nuts (F).
7. Attach the glass shade to fixture, then secure it with three support rods.







8. Install bulb (not included). See relamping label at socket area or packaging for maximum allowed wattage.
9. Angled mounting recommended for a vaulted or angled ceiling. (See Fig.1)

**Turn on the power at fuse or circuit box.**

The following parts are available for re-order if damaged or missing.

**Spare Parts List:**



A: 6-3/4"  
B: 13-5/8~55-5/8"